



INSTALLATION GUIDE



Watch on Youtube







哔哩哔哩观看安装视频

[EN] [RU] [JP]

X24-DUET-X5A4D18-V2

Component List



[EN]

- 1) Heatsink
- 2) Fan
- 3) Intel Backplate
- 4) Intel Bracket
- 5) AMD Bracket
- 6) Stud bolt
- 7) Tightening Nut
- 8) Thermal Grease
- 9) Fan Clip×4
- 10) PWM Splitter

[RU]

- 1) Кулер
- 2) Вентилятор
- 3) Бэплейт для Intel
- 4) Крепления Intel
- 5) Крепления AMD
- 6) Двусторонний болт
- 7) Затяжная гайка
- 8) Термопаста
- 9) Зажим вентилятора×4
- 10) Разветвитель PWM

[JP]

- 1) ヒートシンク
- 2) ファン
- 3) Intel用バックプレート
- 4) Intel用ブラケット
- 5) AMD用ブラケット
- 6) 六角スペーサー 両オス
- 7) 締め付けナット
- 8) 熱伝導グリス
- 9) ファンクリップ
- 10) PWM対応分岐ケーブル

Choose Components for Sockets:

LGA1851/1700/1200/115X:

1 2 3 4 6 7 8

AMD AM4/AM5:

1 2 5 6 7 8

How to choose the correct bracket

Intel



AMD




LGA1200/115X

LGA1851/1700



AM4 / AM5


Intel LGA1851/1700/1200/115X



Component No.

1 2 3 4 5 6 7 8



AMD AM4/AM5



Component No.

1 2 5 6 7 8

Fan Mounting & Connection



[EN]

Secure the fan to the heatsink with fan clips.
Plug fan 4pin power cable to "CPU_FAN" header.

[RU]

Закрепите вентилятор на радиаторе зажимами для вентилятора.
Подключите 4-контактный кабель питания вентилятора к разъему "CPU_FAN".

[JP]

ファン固定用クリップでファンをヒートシンクに固定します。
次に、ファンの4ピン電源ケーブルを「CPU_FAN」ヘッダーに接続します。

Have Questions ?

- Please ask for professional help if you don't know how to install.
- Make sure you're working on a power-off PC.
- If you have any doubt about components list or product itself, please contact your original reseller/retailer/etailer.
- ID-COOLING is always ready to offer our support. You can find the contact information below.
- Descriptions are for your reference. Different models may vary in terms of components list.

SHENZHEN BUYEASY CO., LTD.
www.idcooling.com
support@idcooling.com



idcooling.gkbat



youtube.com/c/idcooling



X24-DUET